

ND MX-5 Miata Vent Mount

Thank you for purchasing the ND MX-5 Miata Vent Mount system from CravenSpeed. This kit is made from the highest grade materials and is guaranteed to be free of defects.

Parts included:

1 ea Vent Mount

Options

- **(Gemini Magnetic Phone Mount)**

- 1 ea Tibia w/ Ball
- 1 ea Gemini Magnet w/
Adhesive Metal Plate
- 1 ea ¼-20 Button Head Cap Screw
- 1 ea Nylon Washer

- **(XXL Phone Mount)**

- 1 ea Tibia w/ Universal Scissor Phone Mount
- 1 ea ¼-20 Button Head Cap Screw
- 1 ea Nylon Washer

- **(FlexPod Gauge Cup)**

- 1 ea FlexPod Gauge Cup (52mm or 60mm)
- 1 ea ABS Gauge Cup Backing Plate
- 2 ea Adhesive-Backed Foam Bumpers
- 1 ea ¼-20 Cap Head Screw
- 1 ea Nylon Washer
- 1 ea Plastic Cap

Tools Required:

5/32" Allen Key

Thin Metal Blade (table knife or similar)

Small Flat-bladed Screwdriver



Disassembly Procedure

1. Choose which vent you would like to install the mount on. Slip a thin metal bladed tool between the vent trim ring and the surface of the dash. Gently twist the tool to release the trim ring clips. There are four clips located at approx the 1, 4, 7, and 10 o'clock positions.



2. Once you have the trim ring popped off, use a small, flat-bladed screwdriver and release the vent assembly clips from the dash as follows:
 - Place the screwdriver just inside the four plastic tabs at an extreme angle and gently pry the inner clips loose. The inner clips need to be pried toward the center of the vent.



NOTE: It may be helpful to grasp the center of the vent and gently pull on the assembly as each of the four clips release.





***The above images show the required position of the screwdriver in relation to the clips.**



Assemble and Install Vent Mount

1. Take the CravenSpeed Vent Mount, line up the gap in the ring with the raised, 'rib' section on the outer surface of the vent assembly.



2. Press the two pieces together until the (4) clips of the vent assembly fully engage the groove inside the Vent Mount. You should be able to hear or sense the clips as they set into place.



3. Set the vent trim bezel back onto the vent assembly making sure the (4) mounting clips are lined up properly and press together till the clips all fully engage.



4. With the mounting tab on the Vent Mount oriented straight up, place the assembly back into the receptacle on the dash and with gentle but firm pressure, push the assembly into the dash until it fully seats.



5. You are now ready to mount your accessory of choice!



Accessory Mounting Options

Gemini Magnetic Phone Mount (or) XXL Phone Mount



Accessory Gauge Pod



If you have any questions about this installation, we would be happy to help.

You can email us: info@avpontheroad.be